



RTK Guide


Connecting DJI Products to NTRIP

Connect DJI controller to WiFi

- If you are away from a 'landline' WiFi network, you will need to enable WiFi hotspot on your phone.
- Connect the DJI controller to the appropriate WiFi network

Setup NTRIP on the DJI controller

- In the main menu of the DJI controller, select RTK
- Ensure the RTK toggle switch is enabled (green)
- Under RTK Service Type, select 'Custom Network RTK'



- Input the following parameters:
 - NTRIP Host: ntrip.cseq.co.uk
 - Port: 2101
 - User / Password: Supplied separately
 - Mountpoint: Type in the nearest mountpoint (list supplied separately)
 - Press Connect

The drone should obtain RTK fix within 2 minutes - You are now ready for flight.